



GUCCI

INTERCHANGEABLE SYSTEM U-PLAY

1. Unscrew the bezel and remove the 2 bracelet elements as shown on the following images A, B and C.



2. Start by inserting the new bracelet and ensure the right position of the inserts.



3. Finally place the bezel aside as shown on the following image D. Match the red dots of the bezel and the case, return the bezel on the case (image E) and screw of a quarter.

You must hear a «click» to be sure the bezel is at the right position.




Not suitable for children under 36 months of age.


GUCCI

INTERCHANGEABLE SYSTEM U-PLAY BANDEAU

1. Unscrew and remove the bezel then push the case in order to remove the bracelet as shown on the following images A, B and C.



2. Start by inserting the new bracelet in the case and ensure the right position of the inserts.



3. Finally place the bezel aside as shown on the following image D. Match the red dots of the bezel and the case, return the bezel on the case (image E) and screw of a quarter.
You must hear a «click» to be sure the bezel is at the right position.



Not suitable for children under 36 months of age.